

377 Adhesive Roll-on

Flügger Adhesive is an aqueous adhesive for hanging wall coverings.

Properties

Ready-mixed, transparent, reinforced adhesive. For hanging a lightweight wall covering where the adhesive is applied to the wall.

- · Adhesive, light wall covering
- Widely applicable
- Can be sprayed on



Labelling

Name: 12 L	✓
Name: 5 L	✓
Name: 0,75 L	✓

Use

Indoors in a dry room for hanging a lightweight wall covering 30-130 g/m2, e.g. glass felt, fibre felt, structural felt and glass fabric.

On concrete, lightweight concrete, plaster, gypsum board, fibreglass, wood-fibre boards, veneer sheets, chipboard and sandblasted substrates.

Substrate

Must be clean, dry, firm and suitable for substrate treatment.

Treatment

Remove loose material and paint by cleaning and sanding.

Remove dirt, grime, grease and chalking materials by cleaning with Fluren 37.

Water-soluble discolouration, nicotine and soot can be cleaned with Fluren 49 and treated with Stop Primer.

Hard, smooth substrates should be sanded to a matt finish and primed as required using Fix Primer.

Cracks, unevenness and holes must be filled.

Absorbent and porous substrates can be primed with Sealer.

Untreated, painted and wallpapered substrates can be primed with Combi Primer.

Application

Apply on wall using brush, roller or spray gunwith after rolling.

Adjust layer thickness to substrate and wall covering.

Apply uniformly wet on wet and finish by brushing/rolling in the same direction.

Allow the adhesive to dry briefly before hanging the wall covering.

Differences in layer thickness or uneven structure can result in a non-uniform substrate.

Insufficient layer thickness results in the risk of blistering and inadequate adhesion.

Excess layer thickness results in the risk of cracking and visible stains.

Adhesive applied to the front of the wallpaper may cause visible stains.

Cold/heat can affect the viscosity of the material.

Condensation must be prevented during drying/curing.

Cold and increased atmospheric humidity extends drying time and full curing.

Increased temperature and low atmospheric humidity reduce drying time and full curing.

Always perform a test treatment for a check and acceptance of adhesion and result.

Expected result

Uniform and well fastened to substrate.

Does not prevent penetration of knots and water-soluble dyes, water stains and nicotine.

Can be painted over when wall covering and adhesive are completely dry.

Exercise care in loading the substrate until the adhesive is fully cured.

Please note!

Ensure good ventilation during and after hanging.

Environmental information

Clean off the paint from tools and wash them with water. Bring remains of fluent paint to the local recycling centre. Minimize your paint waste by pre-estimating how much paint you need. Keep the leftover paint for future use so you can effectively reduce the environmental impact.

Storage: Cool, frost free and tightly closed

Protection equipment: Spray painting: painting suit, full face mask with combined filter. Painting: eye protection, gloves. Sanding: respiratory protection

Technical Data

Bonding and Glue
1.04
20
16
5
Min. +15°C
Max. humidity 80 % RH.
Do not dilute
Water

Current TDS Version

January 2021

Replaces TDS Version

October 2020